AC0WY-03

## INSTALLATION

1. GS430:

## **INSTALL COMPRESSOR**

- (a) Install the compressor with the 2 bolts temporarily.
- (b) Install the compressor stay with the bolt and nut temporarily.
- (c) Tighten the nut and 3 bolts.

Torque:

Bolt: 49 N·m (500 kgf·cm, 36 ft·lbf) Nut: 29 N·m (300 kgf·cm, 22 ft·lbf)

- (d) Connect the connector.
- 2. GS430:

**CONNECT DISCHARGE HOSE** 

Connect the discharge hose with the nut.

Torque: 10 N·m (100 kgf·cm, 7 ft·lbf)

**NOTICE:** 

Hose should be connected immediately after the cap have been removed.

HINT:

Lubricate a new O-ring with compressor oil and install them to the hose.

3. GS430:

## **INSTALL SUCTION HOSE**

Install the suction hose with the bolt and nut.

Torque: 10 N·m (100 kgf·cm, 7 ft·lbf)

NOTICE:

Hose should be connected immediately after the caps have been removed.

HINT:

Lubricate 2 new O-rings with compressor oil and install them to the hose.

4. INSTALL DRIVE BELT

(See page AC-4)

5. INSPECT DRIVE BELT TENSION

(See page AC-2)

- 6. INSTALL ENGINE UNDER COVER
- 7. CONNECT NEGATIVE (-) TERMINAL CABLE TO BATTER
- 8. EVACUATE AIR FROM REFRIGERATION SYSTEM AND CHARGE SYSTEM WITH REFRIGERANT Specified amount:  $600 \pm 50 \text{ g}$  (21.16  $\pm$  1.76 oz.)
- 9. INSPECT FOR LEAKAGE OF REFRIGERANT

Using a gas leak detector, check for leakage of refrigerant.

If there is leakage, check the tightening torque at the joints.

10. INSPECT A/C OPERATION