

## BRAKE INSPECTION

MA01R-07

- 1. INSPECT BRAKE PEDAL AND PARKING BRAKE (See Pub. No. RM588E)
- 2. INSPECT BRAKE LINE PIPES AND HOSES HINT:

Check in a well lighted area. Check the entire circumference and length of the brake hoses using a mirror as required. Turn the front wheels fully right or left before checking the front brake.

- (a) Check all brake lines and hoses for.
  - Damage
  - Wear
  - Deformation
  - Cracks
  - Corrosion
  - Leaks
  - Bends
  - Twists
- (b) Check all clamps for tightness and connections for leakage.
- (c) Check that the hoses and lines are clear of sharp edges, moving parts and the exhaust system.
- (d) Check that the lines install in grommets pass through the center of the grommets.
- 3. INSPECT FRONT AND REAR BRAKE PADS AND DISCS (See Pub. No. RM588E)
- 4. INSPECT PARKING BRAKE LININGS AND DRUMS (See Pub. No. RM588E)
- 5. INSPECT OR CHANGE BRAKE FLUID (See Pub. No. RM588E)

Fluid: SAE J1703 or FMVSS No.116 DOT3